

AM/FM Stereo Wrap Around Headset Radio

OWNER'S MANUAL — Please read before using this equipment.

Your RadioShack AM/FM Stereo Wrap Around Headset Radio is perfect for anyone on the go! You can wear the radio without messing up your hair. Extended Bass delivers added low-frequency punch.

THE FCC WANTS YOU TO KNOW

Your radio might cause TV or radio interference even when it is operating properly. To determine whether your radio is causing the interference, turn off your radio. If the interference goes away, your radio is causing it. Try to eliminate the interference by:

- moving your radio away from the receiver
- contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using your radio.

This device complies with Part 15 of the *FCC Rules*. Operation is subject to the condition that this device does not cause harmful interference.

INSTALLING A BATTERY

Your headset radio requires one AAA battery (not supplied) for power. For the best performance and longest life, we recommend a RadioShack alkaline battery.

Caution: Use only a fresh battery of the required size and recommended type.


1. Lift the battery compartment cover located in the middle of the headset.
2. Insert one AAA battery in the compartment, according to the polarity marks (+ and -) inside.
3. Close the cover.

When the sound becomes weak or distorted or the headset radio stops operating properly, replace the battery.

Warning: Dispose of the old battery promptly and properly. Do not burn or bury it.

Caution: If you do not plan to use the radio with a battery for a month or longer, remove the battery. Batteries can leak chemicals that can destroy electronic parts.

USING THE HEADSET RADIO



Listening Safely

To protect your hearing, follow these guidelines when you use the headphones.

- Set the volume to the lowest setting before you begin listening. After you begin listening, adjust the volume to a comfortable level.
- Do not listen at extremely high volume levels. Extended high-volume listening can lead to permanent hearing loss.
- Once you set the volume, do not increase it. Over time, your ears adapt to the volume level, so a volume level that does not cause discomfort might still damage your hearing.

Traffic Safety

Do not wear headphones while operating a motor vehicle or riding a bicycle. This can create a traffic hazard and could be illegal in some area.

Even though some headphones let you hear some outside sounds when listening at normal levels, they still can present a traffic hazard.

WEARING THE HEADSET

For the best fit, position the headset so the foam pads beneath the ear clips rest on your ears. Adjust the headset's angle for comfort and performance.

CHANGING THE TRANSPARENT COVERS

You can change the transparent covers on the earpieces with the blue ones (supplied).

Lift the legs of the orange covers and remove the covers from each earpiece. Then align and snap the blue cover onto each earpiece.

CARE

Keep the headset dry; if it gets wet, wipe it dry immediately. Use and store the headset only in normal temperature environments. Handle the headset radio carefully; do not drop it. Keep the headset radio away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

Modifying or tampering with the headset radio's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it. If your headset radio is not performing as it should, take it to your local RadioShack store for assistance.

SPECIFICATIONS

Frequency Coverage:	
AM	530 kHz–1710 kHz
FM	88 MHz –108 MHz
Output Power	12 mW + 12 mW
Power Requirements	One AAA Battery
Alkaline Battery Life	
0.5 mW AM	About 69 Hours
0.5 mW FM Stereo	About 56 Hours
Weight with Battery	3.8 oz (108 g)
Accessory	Blue Transparent Covers

Specifications are typical; individual units might vary. Specifications are subject to change and improvement without notice.

Limited Ninety-Day Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

We Service What We Sell

12/99